

Display Information File の使用方法

Display Information File について

ダウンロードした Display Information File には Windows の環境下でモニタの性能を十分引き出して使用するように、モニタ解像度等の情報が入っています。

下記の手順でシステムにインストールを行ってください。

必要なシステム環境：

Windows 98、Windows Me、Windows 2000 または Windows XP の何れかがインストールされたシステムが必要となります。

ご使用になっているシステム（グラフィックスカード等含む）がプラグ&プレイに対応している場合には、自動的に本ディスプレイを認識します。但し、この場合システム（グラフィックスカード等含む）のプラグ&プレイ機能の設定を有効しておかなければなりません。設定の方法は、お使いのシステムまたはグラフィックスカードの取扱説明書をお読みください。

Windows XP へのインストール手順

本機をお使いのシステムにはじめてつないだときに、「新しいハードウェア」のメッセージが表示される場合もありますが、以下の例にしたがってインストールしてください。

- Step 1: Windows XP を立ち上げます。
- Step 2: スタートボタンをクリックして、「コントロールパネル (C)」を選択します。
- Step 3: 「デスクトップの表示とテーマ」アイコンを選択し、「画面」アイコンをダブルクリックします。
- Step 4: 「画面のプロパティ」表示から、上部の「設定」タブをクリックします。
- Step 5: ディスプレイの表示された画面になりますので、下側の「詳細設定 (V)」ボタンをクリックします。
- Step 6: モニタとアダプタのウィンドウ画面が表示されますので、上部の「モニタ」タブをクリックします。
- Step 7: 「モニタの種類」の画面になりますので、「プロパティ (P)」ボタンをクリックします。
- Step 8: モニタのプロパティウィンドウが表示されますので、「ドライバ」タブをクリックします。
- Step 9: 右下の「ドライバ更新 (P)」ボタンをクリックします。
- Step 10: 「一覧または特定の場所からインストールする (詳細) (S)」を選択して、「次へ> (N)」ボタンをクリックします。
- Step 11: 「検索しないで、インストールするドライバを選択する (D)」を選択して、「次へ> (N)」ボタンをクリックします。
- Step 12: Web サイトからダウンロードした Display Information File を指定します。
- Step 13: 「OK」ボタンを押します。
- Step 14: 「デバイスドライバの選択」画面の「モデル (D)」欄リストの中よりご使用の TOTOKU ディスプレイを選択し、「次へ> (N)」ボタンをクリックします。
- Step 15: このとき、「このハードウェアは～ Windows XP との互換性を検証する Windows ログテストに合格していません。…」表示の出る場合もありますが、「続行 (C)」ボタンをクリックします。
- Step 16: ファイルが読み込まれますと、「ハードウェアの更新ウィザードの完了」と表示されます。「完了」ボタンをクリックします。
- Step 17: Step 8 の表示に戻ります。下側の「閉じる」ボタンをクリックします。
- Step 18: Step 6 の表示に戻りますので、「OK」ボタンをクリックします。
- Step 19: Step 4 の表示に戻りますので、「OK」ボタンをクリックします。

これでディスプレイ インフォメーション ファイルの設定は終了です。

Windows XP のバージョン、設定状態、または、グラフィックスカードメーカーのドライバによっては、画面表示の異なる Step もありますのでご注意ください。

Windows 2000 へのインストール手順

本機をお使いのシステムにはじめてつないだときに、「新しいハードウェア」のメッセージが表示される場合もありますが、以下の例にしたがってインストールしてください。

- Step 1: Windows 2000 を立ち上げます。
- Step 2: スタートボタンをクリックして、「設定 (S)」－「コントロールパネル (C)」を選択します。
- Step 3: コントロールパネルの中の「画面」アイコンをダブルクリックします。
- Step 4: 「画面のプロパティ」表示から、上部の「設定」タブをクリックします。
- Step 5: ディスプレイの表示された画面になりますので、下側の「詳細 (V)」ボタンをクリックします。
- Step 6: モニタとアダプタのウィンドウ画面が表示されますので、上部の「モニタ」タブをクリックします。
- Step 7: 「モニタの種類」の画面になりますので、「プロパティ (P)」ボタンをクリックします。
- Step 8: モニタのプロパティウィンドウが表示されますので、「ドライバ」タブをクリックします。
- Step 9: 右下の「ドライバ更新 (P)」ボタンをクリックします。
- Step10: 「デバイス ドライバのアップグレードウィザードの開始」画面に変わります。
「次へ> (N)」ボタンをクリックします。
- Step11: 「このデバイスの既知のドライバを表示して、その一覧から選択する」を選択して、
「次へ> (N)」ボタンをクリックします。
- Step12: Web サイトからダウンロードした Display Information File を指定します。
- Step13: 「OK」ボタンを押します。
- Step14: 「デバイスドライバの選択」画面の「モデル (D)」欄リストの中よりご使用の TOTOKU ディスプレイを選択し、「次へ> (N)」ボタンをクリックします。
- Step15: 「デバイスドライバのインストール開始」画面になりますので、再度「次へ> (N)」ボタンをクリックします。
- Step16: 「デジタル署名が見つかりませんでした」のウィンドウが表示された場合は、「はい (Y)」ボタンをクリックします。
- Step17: ファイルが読み込まれますと、「デバイスドライバのアップグレードウィザードの完了」と表示されます。
- Step18: Step 8 の表示に戻ります。下側の「閉じる」ボタンをクリックします。
- Step19: Step 6 の表示に戻りますので、「OK」ボタンをクリックします。
- Step20: Step 4 の表示に戻りますので、「OK」ボタンをクリックします。

これでディスプレイ インフォメーション ファイルの設定は終了です。

Windows 2000 のバージョン、または、グラフィックスカードメーカーのドライバによっては、画面表示の異なる Step もありますのでご注意ください。

Windows 98 および Windows Me へのインストール手順

本機をお使いのシステムにはじめてつないだときに、「新しいハードウェア」のメッセージが表示される場合もありますが、以下の例にしたがってインストールしてください。

- Step 1: Windows 98(または Windows Me) を立ち上げます。
- Step 2: スタートボタンをクリックして、「設定 (S)」－「コントロールパネル (C)」を選択します。
- Step 3: コントロールパネルの中の「画面」アイコンをダブルクリックします。

- Step 4: 「画面のプロパティ」表示から、上部の「設定」タブをクリックします。
- Step 5: ディスプレイの表示された画面になりますので、下側の「詳細 (D)」ボタンをクリックします。
- Step 6: 画面がアダプタメーカーのプロパティ「全般」表示になります。
上部の「モニタ」タブをクリックします。
- Step 7: 「モニタ」表示画面になりましたら、「変更 (C)」ボタンをクリックします。
- Step 8: 「デバイス ドライバの更新ウィザード」画面に変わります。
「次へ>」ボタンをクリックします。
- Step 9: 画面より「特定の場所にあるすべての…」を選択します。
「次へ>」ボタンをクリックします。
- Step10: Web サイトからダウンロードした Display Information File を指定します。
- Step11: 「モデル (D)」欄リストの中よりご使用の TOTOKU ディスプレイを選択します。
- Step12: 機種を選択が済んだら、「次へ>」ボタンをクリックします。
ドライバファイルの検索画面になりますので、再度「次へ>」ボタンをクリックします。
- Step13: ファイルが読み込まれますと、
「ハードウェア デバイス用に選択したドライバがインストールされました。」と表示されます。
「完了」ボタンをクリックしてください。
- Step14: Step 7 の表示に戻ります。下側の「適用 (A)」ボタンをクリックします。
そして「OK」ボタンをクリックします。
- Step15: Step 4 の「画面のプロパティ」表示に戻りますので、「OK」ボタンをクリックします。

これでディスプレイ インフォメーション ファイルの設定は終了です。

Windows 98 のバージョン、または、グラフィックスカードメーカーのドライバによっては、画面表示の異なる Step もありますのでご注意ください。

※プラグ&プレイで自動認識された場合は Step8 からの手順となります。

Installing the display information file

A configuration file called display information file downloadable from our website carries the necessary information for the display to perform at its best in Windows environments.



If the computer and the graphics card support Plug and Play and when it is enabled, the display will be automatically recognized. In that case, the following procedure is not necessary. For instructions on how to enable Plug and Play, refer to the instruction manuals for the computer and the graphics card.

When the display is hooked up to the computer for the first time, the Found New Hardware Wizard may start up. However, disregard it and follow the appropriate instructions below for the operating system. Please note that dialog boxes and tabs may be named differently depending on the operating system version and the graphics card driver being used.

Supported operating systems: Microsoft Windows XP, 2000, ME, and 98

For Windows XP

1. Start up Windows XP.
2. Access **Display Properties** by clicking (**Settings**)>**Control Panel**>(Appearance and Themes)>**Display** from the **Start** menu, or right-clicking anywhere on the desktop and selecting **Properties**.
3. Select the **Settings** tab and click "Advanced."
4. A properties dialog box appears. Select the **Monitor** tab and click "Properties."
5. The Plug and Play Monitor Properties dialog box appears. Select the **Driver** tab and click "Update Driver."
6. The Hardware Update Wizard starts up. Select "No, not this time" and click "Next."
7. Select "Install from a list or specified location (Advanced)" and click "Next."
8. Select "Don't search. I will choose the driver to install" and click "Next."
9. With "Show compatible hardware" being checked, click "Have Disk."
10. The Install From Disk screen appears. Enter or browse to the location of the display information file downloaded from the website and click "OK."
11. Select the connected TOTOKU display from the **Model** list and click "Next."
12. The Hardware Installation screen may appear. Click "Continue Anyway."
13. When installation is completed, the Completing the Hardware Update Wizard screen appears. Click "Finish" to end the wizard.
14. In the TOTOKU display Properties dialog box (Step 5), click "Close."
15. In the Plug and Play Monitor and ... dialog box (Step 4), click "OK."
16. In the Display Properties dialog box (Step 2), click "OK."

For Windows 2000

1. Start up Windows 2000.
2. Access **Display Properties** by clicking **Settings>Control Panel>Display** from the **Start** menu, or right-clicking anywhere on the desktop and selecting **Properties**.
3. Select the **Settings** tab and click "Advanced."
4. A properties dialog box appears. Select the **Monitor** tab and click "Properties."
5. The Plug and Play Monitor Properties dialog box appears. Select the **Driver** tab and click "Update Driver."
6. The Upgrade Device Driver Wizard starts up. Click "Next."
7. Select "Display a list of the known drivers for this device so that I can choose a specific driver" and click "Next."
8. With "Show compatible hardware" being selected, click "Have Disk."
9. The Install From Disk screen appears. Enter or browse to the location of the display information file downloaded from the website and click "OK."
10. Select the connected TOTOKU display from the **Model** list and click "Next."
11. When the Start Device Driver Installation screen appears, click "Next."
12. If the Digital Signature Not Found screen appears, click "Yes."
13. When installation is completed, the Completing the Upgrade Device Driver Wizard screen appears. Click "Finish" to end the wizard.
14. In the TOTOKU display Properties dialog box (Step 5), click "Close."
15. In the Plug and Play Monitor and ... dialog box (Step 4), click "OK."
16. In the Display Properties dialog box (Step 2), click "OK."

For Windows 98/ME

Note: If the display is automatically recognized via Plug and Play, start from Step 5.

1. Start up Windows 98 or ME.
2. Access **Display Properties** by clicking **Settings>Control Panel>Display** from the **Start** menu, or right-clicking anywhere on the desktop and selecting **Properties**.
3. Select the **Settings** tab and click "Advanced."
4. A properties dialog box appears. Select the **Monitor** tab and click "Change."
5. The Update Device Driver Wizard starts up. Click "Next."
6. Select "Display a list of all the drivers in a specific location, so you can select the driver you want" and click "Next."
7. Click "Have Disk."
8. The Install From Disk screen appears. Enter or browse to the location of the display information file downloaded from the website and click "OK."
9. Select the connected TOTOKU display from the **Models** list and click "Next."
10. When installation is completed, the following message appears: "Windows has finished installing an updated driver for your hardware device." Click "Finish."
11. On the Monitor tab (Step 4), click "Apply" and click "OK."
12. In the Display Properties dialog box (Step 2), click "OK."